

**BEW - Basic Empty Weight**

Unusable fluid

**BOW - Basic Operating Weight**

Unusable fluid + CREW

**BOW + Payload = ZFW (Zero Fuel Weight)**

**ZFW + Fuel = Ramp Weight/Gate Weight**

**Ramp Weight - TAXI fuel = Take off Weight**

**Take off weight - Trip Fuel = Landing Weight**